

BENNING PC-Win MM 11

Version: 2.2.2.0 for Windows® 98/ ME/ 2000/ XP/ Vista

Note:

1. If your system did not meet the minimum system requirement(s), the installer will abort the setup.
2. Please close all running programs (including antivirus program) and run disk defragmenter prior to starting the BENNING PC-Win MM 11 program.

The Software BENNING PC-Win MM 11 exists of the program BENNING PC-Win MM 11 "Online" and the program BENNING PC-Win MM 11 "Download".

The program BENNING PC-Win MM 11 "Online" keeps an account of a series of measurements that are measured with the Digital Multimeter BENNING MM 11 on a PC or Laptop. The software allows the recording of a series of measurements up to 80.000 measurement values (Windows® 98/ ME) and 100.000 measurement values (Windows® 2000/ XP/ Vista). The recorded series of measurements can be saved in a text file for the purpose of taking notes or for future usage. The transfer of the data is done by means of an optical interface, so that the PC or Laptop is not connected to the measurement signal.

The program BENNING PC-Win MM 11 "Download" allows to download the stored measurements of the storage and the data logger of the Digital-Multimeter.

Whereby 1.000 measurements values can be downloaded of the storage and 40.000 measurements values can be downloaded of the data logger.

The downloaded series of measurements can be saved in a text file for the purpose of taking notes or for future usage. The transfer of the data is done by means of an optical interface, so that the PC or Laptop is not connected to the measurement signal.

The following are supplied with the Software BENNING PC-Win MM 11

1. One CD Rom with the Benning PC-Win MM 11
2. One serial data cable with USB-2.0 compatible connector and optical adapter for BENNING MM 11

| | Datum | Name | | Nr. 4398 en |
|--------------|------------|---------|--|-------------|
| Ausgestellt: | 22.08.2006 | Kneffel | | Bl. 1/2 Bl. |
| Geändert: | 27.10.2007 | FPS | | |
| Geprüft: | 17.12.2007 | FPS | | |

Necessary hardware and system requirements

1. IBM or a compatible PC,
2. Pentium II 500 MHz or higher for Windows® 98/Me,
Pentium III 500 MHz or higher for Windows® 2000/ XP
Pentium IV 2 GHz or higher for Windows® Vista,
3. A minimum of 64 MB RAM for Windows® 98/ Me,
A minimum of 128 MB RAM for Windows® 2000/ XP,
A minimum of 1 GB RAM for Windows® Vista,
4. A minimum monitor resolution: 800 x 600 points (16 Bit),
5. Microsoft Windows® 98/ Me/ 2000/ XP/ Vista operation system,
6. A minimum of 30 MB free storage capacity.

Installation of the Software BENNING PC-Win MM 11

1. To install the Software BENNING PC- Win MM 11, place the CD-Rom in the CD- Rom drive. The installation will follow automatically.
2. If the installation does not take place automatically, check your PC or start the file "d:\PCWinMM11\setup.exe", whereby "d" indicates the drive you choose.
3. Follow the installation instructions on the screen
4. When the installation is completed successfully, the new program "BENNING PC-Win MM 11 will appear in the Windows® start up menu.

De-installation of the Software BENNING PC-Win MM 11

1. To de-install the Software BENNING PC-Win MM 11 open the file "BENNING PC-Win MM 11 via the Windows® start up menu and start the file "uninstall BENNING PC-Win MM 11".
2. The de-installation will follow automatically.

Theo Benning GmbH. & CO. KG.

Münsterstraße 135 - 137

D - 46397 Bocholt

Tel : ++49 (0) 2871 93-0, Fax : ++49 (0) 2871 93-429

www.benning.de

e-mail: duspol@benning.de